

How To Use a ZC-9 With a ZonePRO 640/41



Select a ZC-4 in the position (ID #) where the ZC-9 will be used.

Configuration Wizard

ZonePRO Configuration Wizard - ZC Panel Configuration

Enter your ZC panel configuration information



#	Type	Name	Page	Paging Source				Edit	
				Mic 1	Mic 2	S1	S2		
1	ZC 4	Zone Controller						<input type="checkbox"/>	...
	Scene	<input type="checkbox"/>							
2	None	Zone Controller							...
3	None	Zone Controller							...
4	None	Zone Controller							...
5	None	Zone Controller							...
6	None	Zone Controller							...
7	None	Zone Controller							...
8	None	Zone Controller							...
9	None	Zone Controller							...
10	None	Zone Controller							...
11	None	Zone Controller							...
12	None	Zone Controller							...

Cancel < Back Next > Finish

In the Edit window assign which position will select which source. Not all of the binary positions will work. Below shows which binary positions work and which position on the ZC-9 they correspond to.

ZC-4 Setting



This screenshot shows another way of looking at which rotary position corresponds to which binary position.

