

## dbx: ZonePRO 1260-1261-1260m-1261m

This module controls a dbx ZonePRO 1260, 1261, 1260m, or 1261m Router zone over IP



GENERAL INFORMATION	
<b>SIMPLWINDOWS NAME:</b>	dbxZonePRO1260_61_60m_61m_IP_Router.usp
<b>CATEGORY:</b>	Device Interface
<b>VERSION:</b>	V3.0
<b>SUMMARY:</b>	This module controls a dbx ZonePRO 1260, 1261, 1260m, or 1261m Router zone over IP
<b>GENERAL NOTES:</b>	<p><b>IP CONTROL ONLY. USE "dbxZonePRO1260_61_60m_61m_NODE.umc" AND "dbxZonePRO1260_61_60m_61m_Router.umc" MODULE FOR SERIAL COMMUNICATION</b> Port: 3804 TCP</p> <p>This module <b>MUST</b> be used in conjunction with the "dbxZonePRO1260_61_60m_61m_IP_NODE.umc" module. This module will NOT work by itself! Connect the serial "module_rx" and "module_tx" signals to the NODE module. Do NOT connect them directly to the TCP-IP Client Object! (See Node module's help file for more information and setup requirements)</p>
<b>CRESTRON HARDWARE REQUIRED:</b>	2-series or X-series processor

CONTROL:		
<b>Mute</b>	D	Pulse to mute the master output of the router
<b>Unmute</b>	D	Pulse to unmute the master output of the router
<b>Input</b>	A	<p>Sets the input for the router zone:</p> <p>1d: Lobby Mic</p> <p>2d: Phone Page</p> <p>3d: CD L</p> <p>4d: CD R</p> <p>5d: Satellite L</p> <p>6d: Satellite R</p> <p>7d: Jukebox L</p> <p>8d: Jukebox R</p>



		9d: Tv L 10d: Tv R 11d: DvD
<b>Volume</b>	A	Sets the master volume of the router zone. 0d (0%) = -inf (less then -60 dB) 65535d (100%) = 20.0 dB
<b>Module_rx</b>	S	Information coming back from the NODE module. Connect to the 'rx_Module' on the NODE module.
<b>FEEDBACK:</b>		
<b>Mute_fb</b>	D	High when the master output of the router is muted
<b>Input_fb</b>	A	High when the master output of the router is unmuted
<b>Volume_fb</b>	A	Current master volume of the router zone 0d (0%) = -inf (less then -60 dB) 65535d (100%) = 20.0 dB
<b>Module_tx</b>	S	Information being sent to the NODE module. Connect to the 'tx_Module' on the NODE module.
<b>TESTING:</b>		
<b>OPS USED FOR TESTING:</b>	V4.001.1012	
<b>COMPILER USED FOR TESTING:</b>	v2.12	
<b>SAMPLE PROGRAM:</b>	dbxZonePRO1260_61_IP_DemoProgram.smw for 1260 or 1261 and dbxZonePRO1260m_61m_IP_DemoProgram.smw for 1260m and 1261m	
<b>REVISION HISTORY:</b>	v. 1.0 – Creation v. 2.0 – Dbx manufacturer update v. 3.0 – Dbx manufacturer Added support for the 1260m and 1261m	